



4465 West Sam Houston Parkway N. Houston, Texas 77041 WWW.TREEFROGSSHOWROOMS.COM

© 2018 KID STRUCTURES INC.

Sections

Section 1: Cover & Liability Info

Section 2: Product Parts

Section 3: Sub-Assemblies

Section 4: Main Assebmly

Section 5: Roof Options

IMPORTANT - PLEASE READ

As fresh lumber acclimates to its new environment, the natural tendencies of the tree can show itself in the form of checks, or "cracks" in the lumber. In almost all cases this is normal and it will not affect the structural integrity of your play set.

Cosmetic defects that do not affect the structural integrity of the product, or natural defects of wood such as warping, checking or any other physical properties of wood that do not present a safety hazard, are not covered by this warranty.

Defects that develop because the product is exposed to extreme climate conditions are not covered by this warranty. Defects that develop as a result of faulty or improper installation of the product are also not covered by this warranty.

Most cracks are not warrantable, however if you believe that the integrity of your play set is compromised by this natural occurrence, please contact the Tree Frogs Swing Set Dealer that you purchased your swing set from.

We appreciate your purchase and know that you will enjoy your play system for many years to come.

Tools Needed for Assembly

Tape Measure 24" Level Angle Square

Phillips Screw Driver 3/8" Cordless Drill or Electric Drill 3/8" Drive Ratchet or Electric Impact Gun

Claw Hammeror Rubber Mallet Pliers or Vise Grips 7/16" Deep Well Socket

9/16" Deep Well Socket 3/4" Deep Well Socket 1/8", 1/4", and 9/16" Drill Bits

Phillips Head Screw Bits An Adult with two Adult Helpers

Please familiarize yourself with the install manual, parts/components and general construction process of your new swing set before getting started. Approximate assembly time: 6 to 8 hours. 6 foot unobstructed safety perimeter around swingset recommended.

Pre-Assembly Hints

- Depending on your experience, assembly of our play sets can take as little as 6 hours up to 24 hours, depending on size, after inventory of parts; therefore, we recommend you set aside a full two days for assembly.
- Identify all of the parts for your play set. Empty each box and lay out boards so you can see each part. Your instruction book will
 have detailed drawings that will make it easy for you to recognize individual parts. Keep all hardware and metal parts separate
 from wooden pieces.
- After everything is laid out, check carefully to ensure all parts are present. Make sure there are no broken boards.
- Find an area to sort your hardware. It is best to open the hardware on a solid surface so that you do not lose any pieces in the grass.
 - This will save time and familiarize you with all the different pieces in the hardware bag.
 - **Important note: Wood has some natural defects such as knots, surface cracks, etc... We reject parts that are structurally defective. We use a high quality lumber in our structures; however, you should inspect each part for splinters or rough spots and sand them smooth to prevent injury.**
- After familiarizing yourself with all of the components, read all instructions thoroughly. Reading instructions after you have studied the parts will help you understand more clearly the installation process, and help to eliminate unnecessary mistakes.
- Pay close attention to the diameter and length of each bolt and screw.
- Never tighten hardware completely at first. It helps to have some adjustment for bolt alignment while you are attaching parts together. After everything is square, tighten each joint.
- After the main unit is assembled it is critical that the floor is level and square. If the main frame is not level, the walls and floor will be out of square.
- After you complete installation, make sure every bolt, screw, and nut is tight, and every board is secure. Wood will expand and contract with the seasons.
- Place the set on level ground, not less than 6ft from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.
- All 1/4" and 3/8" lag bolts must have pre-drilled holes 1-1/2" to 2" deep. Use a 1/8" drill bit for the 1/4" lag bolts and 1/4" drill bit for 3/8" lag bolts. Use pre-drilled holes in facias as a reference for placing lag bolt pilot holes.
- If a board lifts or rises causing a gap between boards when running in lag bolts or screws, back out the screw or lag bolt and press or apply pressure (but not enough to crack or break board) while re¬running in the lag bolt or screw in the same hole.
- Do not over tighten bolts, lag bolts or screws. You can damage boards, break hardware, and/or strip out the hardware.
- When using hammer do not beat on the hardware, but gently tap it in. Never beat on the wood as it will leave marks.

Leveling Your Swing Set During Assembly

- Complete the steps which will be the basic frame of the fort {i.e. four corner posts with base (sand box boards) and deck supports}
- Position in the most level area chosen for the play set, keeping in mind the location and size of the swing beam, ladder, slides, etc. that extend off the fort.
- Once the frame is in the final position, check for vertical and horizontal levelness to determine which side(s) will need to be dug into the ground to level the play set.
- With a shovel, score the ground around the outside edges of the sandbox boards on the 'high' side of the fort. This is the area that will be dug in. Make sure to score deep enough; the scored lines will be your digging template.
- Push the frame off and away from the scored area, far enough to dig and remove dirt to reach the appropriate depth.
- Dig a channel along the scored line(s) for the base of the fort (corner post and sandbox boards) to rest into. Dig the channel(s) to the same level depth. The bottom of the channel(s) should be level to each other so your frame doesn't teeter or rock because the channel(s) are uneven.
- Once you have removed enough grass and dirt, slide/push the frame into the channel(s). Place a level on the vertical and horizontal boards of the frame to determine if enough soil, or too much, was removed.
- Repeat this process until the basic frame is plumb and level and in its final position before completing the rest of the assembly.
- Measure to make sure fort is square.

^{**} Important: if you require a channel depth of more than 6",then we recommend you have your play set area professionally graded before completing assembly. **

Choosing A Location For Your Playset

When choosing a location for your swing set, always keep your child or children's safety in mind. Here are some recommendations to help you locate and install a safe play area.

- This play set is designed for the use of 4 occupants who have a combined weight not exceeding 800 pounds on the elevated floor; 3 occupants who have a combined weight of 525 pounds on the swing area; for a total Unit capacity of 5 occupants who have a combined weight of 1325. (this weight is not including the picnic table area)
- On-site adult supervision is required.
- The swing set should be located on level ground. The stationary components such as ladders and slides are required to be a minimum of six feet from any structure or obstruction such as a fence, garage, house, tree, overhanging branches, electrical wires, clotheslines, etc. Any swinging equipment is also required to be a minimum distance twice the height of the swing beam away from these obstructions or structures as well. The swing set should be located a safe distance from any water hazards, such as a lake, river, bayou, swimming pool, etc.
- Do not install this residential swing set in a commercial setting. This swing set is not manufactured for commercial usage and will void all warranties. Tree Frogs Wooden Swing Set Factory is not responsible for any damages or injuries resulting from this swing set being used in a commercial setting.
- Never install this swing set indoors; or over concrete, asphalt, packed earth, grass, carpet or any other hard surface. A fall onto a hard surface can result in serious or fatal injury.
- The U.S. Consumer Product Safety Commission (CPSC) recommends that you install and maintain a resilient surface under your swing set. The CPSC's Consumer Information Sheet for Playground Surfacing Materials is on the next page. A resilient surface, should be installed after the swing set has been completely assembled according to these instructions. The swing set must rest on solid ground. Please note that this swing set has a maximum fall height of 7'.

Maintaining Your Swing Set

Here are some maintenance tips required to insure safe play on your swing set for years of fun.

- At the beginning of each usage season and every two weeks during, check: nuts and bolts and tighten as needed, swing seats, chains, ladders, slides, rope and wood components for sign of deterioration and replace if necessary.
- On a yearly basis, we recommend that you coat your swing set with a sealant or preservative. You may also wantto spot sand any areas prior to sealing.
- ** Special note: Although we recommend that you reseal your swing set annually, you may have to touch up the high traffic areas and/or areas that have a high exposure to direct sunlight.**
- Be sure that the sealant you select is non-toxic and child safe. Your local Tree Frogs Wooden Swing Set Factory dealer may offer a complete power wash and reseal and maintenance program.
- Do not use line trimmers or "weed eaters" around your swing set. The line will remove both paint and wood from uprights and base pieces. Any damage resulting from this type of abuse is not covered under our limited warranty.
- Remove plastic swing seats and take in doors or do not use when temperature drops below 0°F.

Please keep this install manual for future reference.

To insure SAFE PLAY adults must teach children:

- Not to walk close to, in front of, behind, or between moving items.
- Not to swing empty swing seats.
- Not to swing sideways into the path of adjacent swings.
- Not to use the swing set in a manner other than that for which it is intended.
- Not to get off the equipment while it is in motion.
- Not to jump off the tower.
- Not to stand in the swing seats.
- Not to swing so high that chains become slack, or above the height of the swing support.
- Not to jump on a slide.
- Not to climb on top of the swing support.
- Not to attach to the swing set any item that is not specifically designed for use with the
 equipment, such as (but not limited to) jump ropes, clotheslines, pet leashes, cables, and
 chains. These may become strangulation hazards.
- To hold on to swings and climbers with both hands.
- To slide feet first, never head first.
- To watch for other children while swinging or playing near the swing set.

To also insure SAFE PLAY adults must:

- Limit climbing and swinging heights to each child's ability.
- Verify that suspended climbing ropes are secured at both ends.
- Verify that suspended climbing ropes cannot be looped back on themselves.
- Dress children appropriately for play. Use well-fitted shoes that do not have slippery soles.
- Avoid ponchos, scarves, hoods, loose fitting clothing, neckties, and any clothing with a drawstring.
 Serious injury could result should any part of the children's clothing become entangled in the swing set.
- Do not allow children to play wearing helmets.
- Remember that children are inventive. When they develop games that are unsafe, be alert and change the rules.

Weight limits for Treefrogs Swingsets

Fort Platform: 800 Lbs. Total Weight. Swing Belts: 175 Lbs.

<u>Trapeze</u>: 125 Lbs. <u>Full Bucket Swing</u>: 50 Lbs.

<u>Toddler Bucket Swing</u>: 50 Lbs. <u>Tire Swing</u>: 125 Lbs. Total Weight

Rope Ladder: 75 Lbs. Rock Wall: 150 Lbs.

All Slides: 125 Lbs.

Tree Frogs recommends that the weight limits for all components must not be exceeded.

Failure to adhere to these and other safety guidelines could result in damage to the swing set.

and/or injury to the users.

CONSUMER INFORMATION SHEET FOR PLAYGROUND SURFACING MATERIALS

The U.S. Consumer Product Safety Commission (CPSC) estimates that about 100,000 playground equipment related injuries resulting from falls to the ground surface are treated annually in U.S. hospital emergency rooms. Injuries involving this hazard pattern tend to be among the most serious of all playground injuries, and have the potential to be fatal, particularly when the injury is to the head. The surface under and around playground equipment can be a major factor in determining the injury-causing potential of a fall. It is self-evident that a fall onto a shock-absorbing surface is less likely to cause a serious injury than a fall onto a hard surface. However, it should be recognized that some injuries from falls will occur no matter what playground surfacing material is used.

Playground equipment should never be placed on hard surfaces such as concrete or asphalt. Grass may appear to be acceptable, but can turn to hard packed earth in areas of high traffic. Shredded bark mulch, wood chips, or fine gravel are considered to be acceptable shock absorbing surfaces when installed and maintained at a sufficient depth under and around play equipment.

MATERIAL	UNCO	MPRESSE	D DEPTH	COMPRESSED DEPTH
	6 Inch	9 Inch	12 Inch	9 inch
Wood Chips	7	10	11	10
Double Shredded Bark Mulch	6	10	11	7
Engineered Wood Fibers	6	7	>12	6
Fine Sand	5	5	9	5
Coarse Sand	5	5	6	4
Fine Gravel	6	7	10	6
Medium Gravel	5	5	6	5

10-12

Shredded Tires**

TABLE 1 -CRITICAL HEIGHTS (in feet) OF TESTED MATERIAL

N/A

N/A

Table 1 should be read as follows: If, for example, uncompressed wood chips are used at a minimum of 6 inches, the Critical Height is 7 feet. If 9 inches of uncompressed wood chips are used, the Critical Height is 10 feet. It should be noted that, for some materials, the Critical Height decreases when the material is compressed. It is recommended that a shock absorbing material should extend a minimum of 6 feet in all directions from the perimeter of stationary equipment such as climbers and slides. However, because children may deliberately jump from a moving swing, the shock absorbing material should extend in the front and rear of a swing a minimum distance of 2 times the height of the pivot point measured from a point directly beneath the pivot on the supporting structure.

This information is intended to assist in comparing the relative shock-absorbing properties of various materials. No particular material is recommended over another. However, each material is only effective when properly maintained. Materials should be checked periodically and replenished to maintain correct depth as determined necessary for your equipment. The choice of a material depends on the type and height of the playground equipment, the availability in your area, and its cost.

This information has been extracted from the CPSC publications "Playground Surfacing-Technical Information Guide" and "Handbook for Public Playground Safety." Copies of these reports can be obtained by sending a postcard to:

Office of Public Affairs
U.S. Consumer Product Safety Commission
Washington, D.C. 20207

Toll-free Hotline: 1-800-638-2772 or at http://www.cpsc.gov

^{**} This is data from tests conducted by independent testing laboratories on a 6 inch depth of uncompressed shredded tire samples produced by four manufacturers. The test reported critical heights, which varied from 10 feet to greater than 12 feet. It is recommended that persons seeking to install shredded tires as a protective surface request test data from the supplier showing the critical height of the material when it was tested in accordance with ASTM F1292.

2018 TREE FROGS Limited Lifetime Warranty

Limited 10-Year Warranty, Limited 5-Year Warranty

Tree Frogs Warranties all Jaguar Playcenter Series, Bengal Forts Series, MegaDeck Fort Series Redwood components and Cedar components against structural failure due to warping, wood rot, insect infestation (excluding Carpenter Bees) or decay for the period of 10 Years from the date of original purchase. This warranty does not cover cracks, fissions, checks, fading, knots and weathering that are normal natural characteristics of wood, that do not affect the structural integrity of the product. The Redwood and Cedar components warranty is extended to a Limited Lifetime Warranty to the original owner upon registering this warranty within 90 days of purchase at www.treefrogsswingsets.com.

Tree Frogs Warranties all Parrot Island Fort Series, Parrot Island Playcenter Series, Rainforest Cottage Series Cedar components against structural failure due to warping, wood rot, insect infestation (excluding Carpenter Bees) or decay for a period of 10 Years from the date of original purchase. This warranty does not cover cracks, fissions, checks, fading, knots and weathering that are normal natural characteristics of wood, that do not affect the structural integrity of the product.

Tree Frogs Warranties all Toucan Fort Series, Toucan Playcenter Series, Orangutan Fort Series, Stand Alone Swings Cedar components against structural failure due to warping, wood rot, insect infestation (excluding Carpenter Bees) or decay for a period of 5 Years from the date of original purchase. This warranty does not cover cracks, fissions, checks, fading, knots and weathering that are normal natural characteristics of wood, that do not affect the structural integrity of the product.

In addition, a 10-Year Limited Warranty applies to all roto-molded slides, ductile iron swing hangers, tire swivels, metal climbing rungs and swing beam brackets against failure due to rust or failure in defect in material. Surface rust, fading, weathering, cracks/chips in coatings and corrosion that do not affect structural integrity are not covered by this warranty. Furthermore, a 5-Year Limited Warranty applies to all components & accessories including all swings, chain ladders, gliders, handles, brackets, bubble panels, tarps, steering/ships wheels, telescopes, binoculars, buoy ball, blow molded slides and disc seat that are not covered under the 10-Year Warranty to be free from defects in material and workmanship. Surface rust, fading, weathering, cracks/chips in coatings and corrosion that do not affect structural integrity are not covered by this warranty.

And for a period of 1-Year Tree Frogs warranties all ropes, structural foam molded slides to be free of defects in material and workmanship. Fading is not considered a defect and may occur with seasonal and geographical conditions.

**10-Year Warranty Exclusion: Toucan Fort Series, Toucan Playcenter Series, Orangutan Series, Stand Alone Swings (Limite 5Yr/5Yr/1Yr WARRANTY).

This warranty is limited to a repair or replacement of the defective part. Product covered under this warranty will be shipped at the customer's expense. Tree Frogs is not responsible for any expense associated with freight, or delivery and installation of the warranted part(s). Tree Frogs reserves the right to inspect all warranty claim parts for which a claim has been made.

This limited warranty applies only to the original retail purchaser and for residential use only, non-residential use voids warranty. These warranties void when product is transferred or sold or no longer in possession by original owner. A copy of the original invoice must be presented to initiate warranty claim. This limited warranty does not cover damage from abuse, acts of God, vandalism, maintenance guideline neglect, alterations, normal wear & tear, use other than residential, unauthorized modification, damage due to moving of product or improper installation and or use. Any modification could damage the structural integrity of the play system and voids all warranties.

This warranty is exclusive and expressly in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for use. Tree Frogs does not assume, or authorize any person to assume for us, any other liability in connection with the sale of our products.

This warranty gives you specific legal rights, and you also may have other rights that vary from state to state. Register your play system's warranty at www.treefrogsswingsets.com.

Tree Frogs reserves the right at any time to change product specifications or substitute similar components.

See your instruction manual for guidelines on regular maintenance. http://treefrogsshowrooms.com/installation-manuals/. Your child's play system & perimeter play zone should be inspected regularly for any wear & safety hazards.

Picture	Description	QTY.
	463-1 43 7/8" Rockwall Board- Ripped	1
	(CC-071) 463-2 43 7/8" Rockwall Board W/ Rope Hole	1
	(CC-068) 463-3 43 7/8" 1- Rock Rockwall Board	7
	(CC-069) 463-4 43 7/8" 2- Rock Rockwall Board	5
	(CC-070) 463-5 43 7/8" Blank Rockwall Board	5
	(CC-088) 463-6 27 1/2" Rail Spindle	15
	(CC-100) 463-7 25" Rail Bottom	6

Picture	Description	QTY.
	(CC-099) 463-8 25" Rail Top	3
	(CC-103) 463-9 28" Rope Rung	8
	(CC-104) 463-10 30" Deck Runner	4
	(CC-116) 463-11 60 3/4" Center Tarp Board	1
	(CC-118) 463-12 67 1/2" Tarp Board	2
	(CC-134) 463-13 54" Deck Board Slim	4
	(CC-135) 463-14 30" Center Deck Support	2

Picture	Description	QTY.
	(CC-124) 463-15 54" Deck Board	8
	(CC-133) 463-16 16 1/2" Ladder Step	7
	(CC-240) 463-17 7 7/8" Small A-Frame Block	1
	(CC-143) 463-18 9" Rope Block	1
	(CC-241) 463-19 16 3/4" A-Frame Block	1
	(CC-242) 463-20 16 3/4" A- Frame Block Sinked	1
	(CC-149) 463-21 19" Left Gusset	5

Picture	Description	QTY.
	(CC-148) 463-22 19" Right Gusset	5
	(CC-142) 463-23 25" Entrapment Block	1
	(CC-173) 463-24 38 7/8" Corner Post	1
	(CC-174) 463-25 70" Ground Runner	1
	(CC-175) 463-26 80 5/8" Center Post	2
	(CC-176) 463-27 100" Upper Rope Arm	1
	(CC-177) 463-28 100" Trapeze Arm	1

Picture	Description	QTY.
	(CC-178) 463-29 102 1/16" Lower Rope Runner	1
	463-30 119 1/2" Top Joist	1
	463-31 119 1/2" Swingbeam Top Joist	1
	463-32 166" 4 POS Swingbeam Header	1
	(CC-188) 463-33 16" Left Gusset	2
	(CC-189) 463-34 16" Right Gusset	2
	(CC-245) 463-35 88" A-Frame Crossmember	1

Picture	Description	QTY.
	463-36 100 1/2" Left Rockwall Leg	1
	463-37 100 1/2" Right Rockwall Leg	1
	463-38 100 1/2" Left Ladder Leg	1
	463-39 100 1/2" Center Pipe & Step Leg	1
	463-40 100 1/2" Right Pipe Ladder Leg	1
	463-41 107" Main Beam	2
	(CC-246) 463-42 143" A-Frame Leg	2

Picture	Description	QTY.
	463-43 166" 4 POS Swingbeam	1

Picture	Description	QTY.
	456-1 15 3/8" Short Fan Board	4
	456-2 19" Wood Roof Support	2
	456-3 20 1/4" Center Fan Board	2
	456-4 21" Long Fan Board	4
	(CC-020) 456-5 25" Wood Roof Support	4
	456-6 69 3/4" Bottom Fan Board	2
	(CC-198) 456-7 14" Center Fan Board	2

Picture	Description	QTY.
	456-8 67 1/2" Wood Roof Top Board	1
	456-9 73 3/8" (L) Wood Roof Runner	2
	456-10 73 3/8" (R) Wood Roof Runner	2
	456-11 67 1/2" Wood Roof Board- Ripped	2
	456-12 67 1/2" Wood Roof Board	34


Picture	Description	QTY.
	(CC-001) 457-1 24 13/16" Panel Filler Support	6
	457-2 4 1/2" Upper Panel Board #9	12
	457-3 7 13/16" Upper Panel Board #2	4
	457-4 10 1/4" Upper Panel Board #12	4
	457-5 10 5/16" Upper Panel Board #3	4
	457-6 16 3/4" Upper Panel Board #5	4
	457-7 18" Window Arch	4

Picture	Description	QTY.
	457-8 19 1/4" Upper Panel Board #6	4
	457-9 19 13/16" Upper Panel Board #7	4
	457-10 42 1/2" Upper Inside Panel Support	4
	457-11 23" Upper Panel Board #11	4
	457-12 6 1516" Upper Panel Board #1	4
	(CC-057) 457-13 14" Left Shutter	4
	(CC-058) 457-14 14" Right Shutter	4

Picture	Description	QTY.
	457-15 14 1/4" Upper Panel Board #4	4
	457-16 23" Upper Panel Board #10	4
	457-17 23 1/16" Upper Panel Board #8	4
	(CC-089) 457-18 27 1/2" Panel Filler	12


463-HWR-BAG- 7.2 JAGUAR PLAYCENTER HARDWARE

INSTALLER NOTE: (YOU MUST ASSEMBLE THIS PRODUCT IN ACCORDANCE WITH THESE ASSEMBLY INSTRUCTIONS. WHEN COMPLETE GIVE MANUAL TO OWNER.)




463-HWR-BAG- 7.2 JAGUAR PLAYCENTER HARDWARE

INSTALLER NOTE: (YOU MUST ASSEMBLE THIS PRODUCT IN ACCORDANCE WITH THESE ASSEMBLY INSTRUCTIONS. WHEN COMPLETE GIVE MANUAL TO OWNER.)




463-HWR-BAG- 7.2 JAGUAR PLAYCENTER HARDWARE

INSTALLER NOTE: (YOU MUST ASSEMBLE THIS PRODUCT IN ACCORDANCE WITH THESE ASSEMBLY INSTRUCTIONS. WHEN COMPLETE GIVE MANUAL TO OWNER.)



453-SB-HWR 7.2 JAGUAR PLAYCENTER SWINGBEAM HARDWARE


INSTALLER NOTE: (YOU MUST ASSEMBLE THIS PRODUCT IN ACCORDANCE WITH THESE ASSEMBLY INSTRUCTIONS. WHEN COMPLETE GIVE MANUAL TO OWNER.)



7.2 JAGUAR PLAYCENTER SWINGBEAM HARDWARE

INSTALLER NOTE: (YOU MUST ASSEMBLE THIS PRODUCT IN ACCORDANCE WITH THESE ASSEMBLY INSTRUCTIONS. WHEN COMPLETE GIVE MANUAL TO OWNER.)


SB-6 1/2" x 12 1/2" Carriage Bolt QTY. 1




7.2 JAGUAR PLAYCENTER SWINGBEAM HARDWARE

INSTALLER NOTE: (YOU MUST ASSEMBLE THIS PRODUCT IN ACCORDANCE WITH THESE ASSEMBLY INSTRUCTIONS. WHEN COMPLETE GIVE MANUAL TO OWNER.)

SB-12 3/8" x 3 1/2" Hex Lag Screw QTY. 2 SB-13 3/8" x 5" Hex Lag Screw QTY. 3



SB-14 #14 x 1" Pan Phillips T/S QTY. 2




SB-15 3/8" Split Lockwasher QTY. 15



SB-16 1/2" Split Lockwasher QTY. 9




SB-17 3/8" USS Flatwasher QTY. 20




SB-22 3/8" Nylon Insert Locknut QTY. 12




SB-18 1/2" USS Flatwasher QTY. 10




SB-19 3/4" USS Flatwasher QTY. 8



SB-20 3/8" Bolt Cup QTY. 15




SB-21 8 x 80mm Spring Clip QTY. 6



7.2 JAGUAR PLAYCENTER SWINGBEAM HARDWARE


INSTALLER NOTE: (YOU MUST ASSEMBLE THIS PRODUCT IN ACCORDANCE WITH THESE ASSEMBLY INSTRUCTIONS. WHEN COMPLETE GIVE MANUAL TO OWNER.)

SB-23 1/2" x 11 1/2" Hex Bolt QTY. 1



456-HWR-BAG- JAGUAR PLAYCENTER WOOD ROOF HARDWARE

INSTALLER NOTE: (YOU MUST ASSEMBLE THIS PRODUCT IN ACCORDANCE WITH THESE ASSEMBLY INSTRUCTIONS. WHEN COMPLETE GIVE MANUAL TO OWNER.)



KSI-457- TREEHOUSE PANEL HARDWARE

INSTALLER NOTE: (YOU MUST ASSEMBLE THIS PRODUCT IN ACCORDANCE WITH THESE ASSEMBLY INSTRUCTIONS. WHEN COMPLETE GIVE MANUAL TO OWNER.)

TP-1 1 1/2" Coated Deck Screw QTY. 216

TP-2 2" Coated Deck Screw QTY. 108

TP-3 #2 & 3 Drive Bit QTY. 1



Picture	Description	QTY.
	463-A 45 Degree Swingbeam Bracket	2
	463-B Swingbeam T-Bracket	1
	463-C 25" Playgrip Tube	3
	463-D 44" Playgrip Tube	1
	463-E Playgrip Safety Handles	4
	463-F Playgrip Ladder Handles	3
	463-G 16' Yellow Rope	1

Picture	Description	QTY.
	463-H 18' Yellow Rope	1
	463-I 19' Yellow Rope	3
	463-J 20" Trpaeze Bar	1
	463-K 66" Plastisol Coated Chain	3
	463-L Disc Swing	1
	463-M Ductile Iron Swing Hanger	8
	463-N Tire Swing Eye Bolt	3

Picture	Description	QTY.
	463-O Tire Swivel	1
	463-P 90" Chained Belt Swing	3
	463-Q Rockwall Rocks	17
	463-R Telescope	1
	463-S 19" Ships' Wheel	1
	463-T 21" x 63" Chain Ladder	1

Rockwall Boards

Rockwall Assembly

(7)


PARTS NEEDED

HARDWARE NEEDED

CC-070- 43 7/8" Rockwall Board Blank-CC-069- 43 7/8" 2-Rock Rockwall Board-463-1- 43 7/8" Rockwall Board Ripped-463-37- 100 1/2" Right Rockwall Leg-

- (5) CC-068- 43 7/8 1- Rock Rockwall Board-
- (5) CC-071- 43 7/8" Rockwall Board w/ Rope Hole- (1)
- (1) 463-36- 100 1/2" Left Rockwall Leg-
- (1) 463-Q- Rockwall Rocks-

- I- 1/4" x 1 1/4" Pan Phillips M/S- (34)
- 1) N- 1/4" USS Flatwasher- (34)
- (1) K- 1/4" T-Nut- (34)
- (17) B- 2 1/2" Coated Deck Screw- (76)



Rockwall Assembly


PARTS NEEDED

HARDWARE NEEDED

 CC-174- 70" Ground Runner (1)
 G- 3/8" x 5" Hex Lag Screw (2)

 CC-148- 19" Right Gusset (1)
 O- 3/8" USS Flatwasher (6)

 CC-149- 19" Left Gusset (1)
 F- 3/8" x 3 1/2" Hex Lag Screw (4)



Chain-Step Ladder Assembly

PARTS NEEDED HARDWARE NEEDED		<u>DED</u>
463-39- 100 1/2" Center Step & Chain Ladder Leg- (1) 463-36- 100 1/2" Left Step Ladder Leg- (1) CC-133- 16 1/2" Step- (7) 463-40- 100 1/2" Right Chain Ladder Leg- (1) 463-T- 21" x 63" Chain Ladder- (1) 463-D- 44" Playgrip Tube- (1) 463-C- 25" Playgrip Tube- (3)	E- 1/4" x 4 1/2" Hex Lag Screw- N- 1/4" USS Flatwasher- J- 2" Metal Tap Screw-	(28) (28) (8)
M63-36		463-40 463-40
E		


Chain-Step Ladder Assembly

PARTS NEEDED

HARDWARE NEEDED

(1) (1) (1) CC-178- 102 1/16" Lower Rope Runner-G- 3/8" x 5" Hex Lag Screw-O- 3/8" USS Flatwasher-CC-148- 19" Right Gusset-CC-149- 19" Left Gusset-

(3) (7) (4) F- 3/8" x 3 1/2" Hex Lag Screw-



Chain-Step Ladder Assembly

Deck Assembly (QTY. 3)

PARTS NEEDED

463-F- Playgrip Ladder Handles-

CC-104- 30" Deck Runner- (6)

CC-135- 30" Center Deck Support-

CC-134- 54" Deck Board- Slim- (6)

CC-124- 54" Deck Board- (12)

HARDWARE NEEDED

H- #14 x 2" Pan Phillips T/S-


(6)

N- 1/4" USS Flatwasher-

(6)

B- 2 1/2" Coated Deck Screw-

(126)




Beam Assembly

A-Frame Block Assembly

PARTS NEEDED

463-32- 166" 4 POS Swingbeam Header-	(1)	SB-10- 3/8" x 10 1/2" Hex Bolt-	(12)	SB-20- 3/8" Bolt Cup-	(15)
463-43- 166" 4 POS Swingbeam-	(1)	SB-17- 3/8" USS Flatwasher-	(16)	SB-15- 3/8" Split Lockwasher-	(15)
CC-241- 16 3/4" A-Frame Block-	(1)	SB-22- 3/8" Nylon Insert Locknut-	(12)	SB-1- 3/8" Acorn Nut Plated-	(15)
CC-240- 7 7/8" Small A-Frame Block-	(1)	SB-13- 3/8" x 5" Hex Lag Screw-	(1)	SB-9- 3/8" x 10" Hex Bolt-	(3)
CC-242- 16 3/4" A-Frame Block Sunk-	(1)	SB-7- 3/8" Hex Nut-	(3)		



Swingbeam Assembly

PARTS NEEDED

HARDWARE NEEDED

CC-246- 143" A-Frame Leg-

(2) SB-23- 1/2" x 11 1/2" Hex Bolt-SB-16- 1/2" Split Lockwasher-


SB-2- 1/2" Acorn Nut Plated-

SB-19-3/4" USS Flatwasher-

(1) SB-18- 1/2" USS Flatwasher-

SB-8- 1/2" Hex Nut-(4)

(3) (3) (2) SB-5- 1/2" x 10 Carriage Bolt-(3)



Tire Swing Set-Up


PARTS NEEDED


HARDWARE NEEDED

463-N- Tire Swing Eye Bolt-463-K- 66" Plastisol Coated Chain-

Hardware with Parts

(3) (3) (1) Tire-






PARTS NEEDED

463-41- 107" Main Beam-	(2)
CC-188- 16 "Right Playcenter Gusset-	(2)
CC-189- 16" Left Playcenter Gusset-	(2)

-			
A-5- 1/2" x 7" Carriage Bolt-	(4)	Q- 3/4" USS Flatwasher-	(4)
P- 1/2" USS Flatwasher-	(4)	M- 1/2" Split Lockwasher-	(4)
C- 1/2" Hex Nut-	(4)	A-2- 1/2" Acorn Nut Plated-	(4)
G- 3/8" x 3 1/2" Hex Lag Screw-	(16)	O- 3/8" USS Flatwasher-	(16)




PARTS NEEDED

CC-173- 38 7/8" Corner Post-CC-175- 80 5/8" Center Post-(2)

HARDWARE NEEDED


A-4- 1/2" x 6 1/2" Carriage Bolt- (6) Q- 3/4" USS Flatwasher- (6) P- 1/2" USS Flatwasher- (6) M- 1/2" Split Lockwasher- (6) C- 1/2" Hex Nut- (6) A-2- 1/2" Acorn Nut Plated- (6)



PARTS NEEDED

(2) (1) (1) Deck Assemblies-463-30- 119 1/2" Top Joist-463-31- 119 1/2" SB Top Joist-


E- 1/4" x 4 1/2" Hex Lag Screw-	(8)	N- 1/4" USS Flatwasher-	(8)
A-4- 1/2" x 6 1/2" Carriage Bolt-	(6)	Q- 3/4" USS Flatwasher-	(6)
M- 1/2" Split Lockwasher-	(6)	P- 1/2" USS Flatwasher-	(6)
C- 1/2" Hex Nut-	(6)	A-2- 1/2" Acorn Nut Plated-	(6)



PARTS NEEDED

CC-148- 19" Left Gusset- (2) CC-149- 19" Right Gusset- (2) CC-176- 100" Upper Rope Arm- (1) CC-177- 100" Trapeze Arm- (1)

O- 3/8" USS Flatwasher-	(12)	F- 3/8" x 3 1/2" Hex Lag Screw-	(8)
A-4- 1/2" x 6 1/2" Carriage Bolt-	(4)	Q- 3/4" USS Flatwasher-	(4)
P- 1/2" USS Flatwasher-	(4)	M- 1/2" Split Lockwasher-	(4)
C- 1/2" Hex Nut-	(4)	A-2- 1/2" Acorn Nut Plated-	(4)
G- 3/8" x 5" Hex Lag Screw-	(4)		



PARTS NEEDED

HARDWARE NEEDED


(4) (4) (6) (6)

 CC-148- 19" Right Gusset (1)
 O- 3/8" USS Flatwasher

 CC-149- 19" Left Gusset (1)
 F- 3/8" x 3 1/2" Hex Lag Screw

 CC-100- 25" Rail Bottom (3)
 D- 1/4" x 3" Hex Lag Screw

 N- 1/4" USS Flatwasher



PARTS NEEDED


HARDWARE NEEDED

CC-142- 25" Entrapment Block-(1) (1) Slide-

O- 3/8" USS Flatwasher-G- 3/8" x 5" Hex Lag Screw(2) (2) (3) (3)

H- #14 x 2" Pan Phillips T/S-


N- 1/4" USS Flatwasher-



PARTS NEEDED

463-E- Playgrip Safety Handle-	(4)
163 M. Ductile Iron Swing Hanger	(2)

N- 1/4" USS Flatwasher-	(8)	H- #14 x 2" Pan Phillips T/S-	(8)
A-6- 3/8" x 5" Hex Bolt-	(4)	A-8- 3/8" Bolt Cup-	(4)
O- 3/8" USS Flatwasher-	(4)	L- 3/8" Split Lockwasher-	(4)
A-7- 3/8" Nylon Insert Locknut-	(4)	A-1- 3/8" Acorn Nut Plated-	(4)





PARTS NEEDED

HARDWARE NEEDED

463-J- Trapeze Bar- (1) 463-l- 19' Yellow Rope- (3) CC-103- 28" Rope Rung- (8) A-9-8 x 80mm Spring Clip-

(2)






SLIDE ONE END OF ROPE THROUGH THE UPPER ROPE ARM AND TIE A GOOD KNOT. THEN TAKE A CC-103 AND SLIDE IT UP ABOUT 1 TO 1 1/2 FT BELOW THE ROPE ARM AND TIE KNOT HOLDING IT. REPEAT FOR ALL CC-103'S AND TIE A KNOT ON THE ROPE RUNNER.

PARTS NEEDED

HARDWARE NEEDED

CC-143- 9" Rope Block-463-H- 18' Yellow Rope(1) (1) O- 3/8" USS Flatwasher-G- 3/8" x 5" Hex Lag Screw-

(2)




SLIDE 463-H THROUGH CC-143 AND TIE A KNOT HOLDING IT IN PLACE. WORK YOUR WAY DOWN TYING A KNOT EVERY 2 TO 3 FEET UNTIL YOU STRING THE ROPE THROUGH ROCK-WALL BOARD WITH ROPE HOLE AND TIE A KNOT SECURING THE ROPE TO THE ROCKWALL.

PARTS NEEDED

463-O- Tire Swivel- (1)

HARDWARE NEEDED


A-3- 1/2" x 4 1/2" Carriage Bolt- (2) Q- 3/4" USS Flatwasher- (2) P- 1/2" USS Flatwasher- (2) M- 1/2" Split Lockwasher- (2) C- 1/2" Hex Nut- (2) A-1- 1/2" Acorn Nut Plated- (2)



PARTS NEEDED

HARDWARE NEEDED


Tire Assembly- (1) A-9- 8 x 80mm Spring Clip- (3)



PARTS NEEDED

463-B- Swingbeam 1- Bracket-	(1	
Swingbeam Assembly-	(1	ı

SB-3- 1/2" x 3 1/2" Carriage Bolt-	(2)	SB-19- 3/4" USS Flatwasher-	(4)
	(-)		`
SB-18- 1/2" USS Flatwasher-	(4)	SB-16- 1/2" Split Lockwasher-	(4)
SB-8- 1/2" Hex Nut-	(4)	SB-2- 1/2" Acorn Nut Plated-	(4)
SB-6- 1/2" x 12 1/2" Carriage Bolt-	(1)	SB-5- 1/2" x 10" Carriage Bolt-	(1)




PARTS NEEDED


(1)

CC-245- 88" A-Frame Crossmember-


SB-13- 3/8" x 5" Hex Lag Screw-	(2)	SB-17- 3/8" USS Flatwasher-	(2)
SB-4- 1/2" x 7" Carriage Bolt-	(2)	SB-19- 3/4" USS Flatwasher-	(2)
SB-18- 1/2" USS Flatwasher-	(2)	SB-16- 1/2" Split Lockwasher-	(2)
SB-8- 1/2" Hex Nut-	(2)	SB-2- 1/2" Acorn Nut Plated-	(2)




AFTER ATTACHING AND LEVELING THE A-FRAME LOCK IN PLACE AS SHOWN



LEVEL CROSSMEMBER ACROSS THE A-FRAME LEGS AND MARK HOLES



USING A 9/16" DRILL BIT DRILL OUT HOLES AND ASSEMBLE AS **SHOWN**




PARTS NEEDED

(1) (1) (1)

HARDWARE NEEDED

463-G- 16' Yellow Rope-463-L- Disc Swing-463-S- 19" Ship's WheelSB-21- 8 x 80mm Spring Clip-

(6)



Tarp Option

PARTS NEEDED

CC-116- Center Tarp Board-

(1) (2) (1) CC-118- Tarp Board-

Tarp-

HARDWARE NEEDED

E- 1/4" x 4 1/2" Hex Lag Screw-


N- 1/4" Uss Flatwasher-

(6)


R- Phillips Screw Snap-

(6) (8)

MARK THE PLACEMENT OF THE TARP SNAPS



Tarp Option



Wood Roof Option

HARDWARE NEEDED


(4) (4)

(4)

(6)

PARTS NEEDED

456-8- Wood Roof Tarp Board (1) A-1- 3/8" Acorn Nut Plated (4) A-2- 3/8" x 5" Carriage Bolt 456-9- Left WR Runner (2) A-5- 3/8-13 Hex Nut (4) A-8- 3/8" Split Lockwasher 456-10- Right WR Runner (2) A-10- 3/8" Uss Flatwasher (4) A-11- 1/2" Uss Flatwasher A-7- 1/4" x 4 1/2" Hex Lag Screw (6) A-9- 1/4" Uss Flatwasher




Wood Roof Option


PARTS NEEDED


HARDWARE NEEDED

456-2- Wood Roof Support-	(2)
CC-020- Wood Roof Support-	(4)
456-11- Wood Roof Board-Ripped-	(2)
456-12- Wood Roof Board-	(32)

A-3- 1 1/4" Coated Deck Screw- (36) A-4- 1 1/2" Coated Deck Screw- (136)









Wood Roof Option

PARTS NEEDED

456-1- Short Fan Board- 456-3- Center Fan Board-	(4) (2)	A-4- 1 1/2" Coated Deck Screw- A-9- 1/4" Uss Flatwasher-	(136) (14)	A-6- 1/4" x 1 1/2" Hex Lag Screw-	(14)
456-4- Long Fan Board-	(4)	7, 0 17, 1 God Hatmaone.	()		
456-6- Bottom Fan Board-	(2)				
456-7- Center Fan Board-	(2)				



WOOD ROOF



Open Rail

PARTS NEEDED


HARDWARE NEEDED

CC-088- Rail Spindle-CC-100- Rail Bottom-CC-099- Rail Top(15) (6) (6)

B- 2 1/2" Coated Deck Screw-

(60)

MAKE 3 OF THESE




Open Rail Install

PARTS NEEDED

HARDWARE NEEDED

Rail Assembly-(3) D- 1/4"x3" Hex Lag Screw-E- 1/4" x 4 1/2" Hex Lag Screw-

(6) (6) (12) N- 1/4" Uss Flatwasher-



Closed Panel


PARTS NEEDED


HARDWARE NEEDED

CC-088- Rail Spindle-	(15)
CC-100- Rail Bottom-	(3)
CC-099- Rail Top-	(3)
457-1- Panel Support-	(6)
CC-089- Lower Panel Filler Board-	(12)

B- #8 x 2 1/2" Coated Deck Screw (30) A-4 #8 x 1 1/2" Coated Deck Screw (108)

MAKE 3 OF THESE





Closed Panel Install

PARTS NEEDED

HARDWARE NEEDED


Solid Rail Assembly-(3)

D- 1/4" x 3" Hex Lag Screw-

(6) (6) (12)

E- 1/4" x 4 1/2" Hex Lag Screw-

N- 1/4" Uss Flatwasher-



Treehouse Panel Install


PARTS NEEDED

HARDWARE NEEDED

457-2- Upper Panel #9-457-11- Upper Panel Board #11-CC-058- Right Treehouse Shutter-457-17- Upper Panel Board #8(12) 457-7- Window Arch-

- (4) A-1- 1 1/2" Coated Deck Screw-(4)
- (64)


- (4) CC-057- Left Treehouse Shutter-
- (4) 457-16- Upper Panel Board #10- (4)
- (4)




Treehouse Panel Install

PARTS NEEDED


457-3- Upper Panel Board #2-	(4)	457-4- Upper Panel Board #12-	(4)	A-1- 1 1/2" Coated Deck Screw-	(104)
457-5- Upper Panel Board #3-	(4)	457-6- Upper Panel Board #5-	(4)		
457-8- Upper Panel Board #6-	(4)	457-9- Upper Panel Board #7-	(4)		
457-10- Upper Inside Panel Support-	(4)	457-12- Upper Panel Board #1-	(4)		
457-15- Upper Panel Board #4-	(4)	• •	. ,		




Treehouse Panel







Extended Monkey Bar Installation Manual





4465 West Sam Houston Parkway N. Houston, Texas 77041 WWW.TREEFROGSSHOWROOMS.COM

Sections

Section 1: Cover & Liability Info

Section 2: Product Parts Section 3: Sub-Assemblies Section 4: Main Assebmly

© 2018 KID STRUCTURES INC.

IMPORTANT - PLEASE READ

As fresh lumber acclimates to its new environment, the natural tendencies of the tree can show itself in the form of checks, or "cracks" in the lumber. In almost all cases this is normal and it will not affect the structural integrity of your play set.

Cosmetic defects that do not affect the structural integrity of the product, or natural defects of wood such as warping, checking or any other physical properties of wood that do not present a safety hazard, are not covered by this warranty.

Defects that develop because the product is exposed to extreme climate conditions are not covered by this warranty. Defects that develop as a result of faulty or improper installation of the product are also not covered by this warranty.

Most cracks are not warrantable, however if you believe that the integrity of your play set is compromised by this natural occurrence, please contact the Tree Frogs Swing Set Dealer that you purchased your swing set from.

We appreciate your purchase and know that you will enjoy your play system for many years to come.

Tools Needed for Assembly

Tape Measure 24" Level Angle Square

Phillips Screw Driver 3/8" Cordless Drill or Electric Drill 3/8" Drive Ratchet or Electric Impact Gun

Claw Hammeror Rubber Mallet Pliers or Vise Grips 7/16" Deep Well Socket

9/16" Deep Well Socket 3/4" Deep Well Socket 1/8", 1/4", and 9/16" Drill Bits

Phillips Head Screw Bits An Adult with two Adult Helpers

Please familiarize yourself with the install manual, parts/components and general construction process of your new swing set before getting started. Approximate assembly time: 6 to 8 hours. 6 foot unobstructed safety perimeter around swingset recommended.

Pre-Assembly Hints

- Depending on your experience, assembly of our play sets can take as little as 6 hours up to 24 hours, depending on size, after inventory of parts; therefore, we recommend you set aside a full two days for assembly.
- Identify all of the parts for your play set. Empty each box and lay out boards so you can see each part. Your instruction book will
 have detailed drawings that will make it easy for you to recognize individual parts. Keep all hardware and metal parts separate
 from wooden pieces.
- After everything is laid out, check carefully to ensure all parts are present. Make sure there are no broken boards.
- Find an area to sort your hardware. It is best to open the hardware on a solid surface so that you do not lose any pieces in the grass.
 - This will save time and familiarize you with all the different pieces in the hardware bag.
 - **Important note: Wood has some natural defects such as knots, surface cracks, etc... We reject parts that are structurally defective. We use a high quality lumber in our structures; however, you should inspect each part for splinters or rough spots and sand them smooth to prevent injury.**
- After familiarizing yourself with all of the components, read all instructions thoroughly. Reading instructions after you have studied the parts will help you understand more clearly the installation process, and help to eliminate unnecessary mistakes.
- Pay close attention to the diameter and length of each bolt and screw.
- Never tighten hardware completely at first. It helps to have some adjustment for bolt alignment while you are attaching parts together. After everything is square, tighten each joint.
- After the main unit is assembled it is critical that the floor is level and square. If the main frame is not level, the walls and floor will be out of square.
- After you complete installation, make sure every bolt, screw, and nut is tight, and every board is secure. Wood will expand and contract with the seasons.
- Place the set on level ground, not less than 6ft from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.
- All 1/4" and 3/8" lag bolts must have pre-drilled holes 1-1/2" to 2" deep. Use a 1/8" drill bit for the 1/4" lag bolts and 1/4" drill bit for 3/8" lag bolts. Use pre-drilled holes in facias as a reference for placing lag bolt pilot holes.
- If a board lifts or rises causing a gap between boards when running in lag bolts or screws, back out the screw or lag bolt and press or apply pressure (but not enough to crack or break board) while re¬running in the lag bolt or screw in the same hole.
- Do not over tighten bolts, lag bolts or screws. You can damage boards, break hardware, and/or strip out the hardware.
- When using hammer do not beat on the hardware, but gently tap it in. Never beat on the wood as it will leave marks.

Leveling Your Swing Set During Assembly

- Complete the steps which will be the basic frame of the fort {i.e. four corner posts with base (sand box boards) and deck supports}
- Position in the most level area chosen for the play set, keeping in mind the location and size of the swing beam, ladder, slides, etc. that extend off the fort.
- Once the frame is in the final position, check for vertical and horizontal levelness to determine which side(s) will need to be dug into the ground to level the play set.
- With a shovel, score the ground around the outside edges of the sandbox boards on the 'high' side of the fort. This is the area that will be dug in. Make sure to score deep enough; the scored lines will be your digging template.
- Push the frame off and away from the scored area, far enough to dig and remove dirt to reach the appropriate depth.
- Dig a channel along the scored line(s) for the base of the fort (corner post and sandbox boards) to rest into. Dig the channel(s) to the same level depth. The bottom of the channel(s) should be level to each other so your frame doesn't teeter or rock because the channel(s) are uneven.
- Once you have removed enough grass and dirt, slide/push the frame into the channel(s). Place a level on the vertical and horizontal boards of the frame to determine if enough soil, or too much, was removed.
- Repeat this process until the basic frame is plumb and level and in its final position before completing the rest of the assembly.
- Measure to make sure fort is square.

^{**} Important: if you require a channel depth of more than 6",then we recommend you have your play set area professionally graded before completing assembly. **

Choosing A Location For Your Playset

When choosing a location for your swing set, always keep your child or children's safety in mind. Here are some recommendations to help you locate and install a safe play area.

- This play set is designed for the use of 4 occupants who have a combined weight not exceeding 800 pounds on the elevated floor; 3 occupants who have a combined weight of 525 pounds on the swing area; for a total Unit capacity of 5 occupants who have a combined weight of 1325. (this weight is not including the picnic table area)
- On-site adult supervision is required.
- The swing set should be located on level ground. The stationary components such as ladders and slides are required to be a minimum of six feet from any structure or obstruction such as a fence, garage, house, tree, overhanging branches, electrical wires, clotheslines, etc. Any swinging equipment is also required to be a minimum distance twice the height of the swing beam away from these obstructions or structures as well. The swing set should be located a safe distance from any water hazards, such as a lake, river, bayou, swimming pool, etc.
- Do not install this residential swing set in a commercial setting. This swing set is not manufactured for commercial usage and will void all warranties. Tree Frogs Wooden Swing Set Factory is not responsible for any damages or injuries resulting from this swing set being used in a commercial setting.
- Never install this swing set indoors; or over concrete, asphalt, packed earth, grass, carpet or any other hard surface. A fall onto a hard surface can result in serious or fatal injury.
- The U.S. Consumer Product Safety Commission (CPSC) recommends that you install and maintain a resilient surface under your swing set. The CPSC's Consumer Information Sheet for Playground Surfacing Materials is on the next page. A resilient surface, should be installed after the swing set has been completely assembled according to these instructions. The swing set must rest on solid ground. Please note that this swing set has a maximum fall height of 7'.

Maintaining Your Swing Set

Here are some maintenance tips required to insure safe play on your swing set for years of fun.

- At the beginning of each usage season and every two weeks during, check: nuts and bolts and tighten as needed, swing seats, chains, ladders, slides, rope and wood components for sign of deterioration and replace if necessary.
- On a yearly basis, we recommend that you coat your swing set with a sealant or preservative. You may also wantto spot sand any areas prior to sealing.
- ** Special note: Although we recommend that you reseal your swing set annually, you may have to touch up the high traffic areas and/or areas that have a high exposure to direct sunlight.**
- Be sure that the sealant you select is non-toxic and child safe. Your local Tree Frogs Wooden Swing Set Factory dealer may offer a complete power wash and reseal and maintenance program.
- Do not use line trimmers or "weed eaters" around your swing set. The line will remove both paint and wood from uprights and base pieces. Any damage resulting from this type of abuse is not covered under our limited warranty.
- Remove plastic swing seats and take in doors or do not use when temperature drops below 0°F.

Please keep this install manual for future reference.

To insure SAFE PLAY adults must teach children:

- Not to walk close to, in front of, behind, or between moving items.
- Not to swing empty swing seats.
- Not to swing sideways into the path of adjacent swings.
- Not to use the swing set in a manner other than that for which it is intended.
- Not to get off the equipment while it is in motion.
- Not to jump off the tower.
- Not to stand in the swing seats.
- Not to swing so high that chains become slack, or above the height of the swing support.
- Not to jump on a slide.
- Not to climb on top of the swing support.
- Not to attach to the swing set any item that is not specifically designed for use with the
 equipment, such as (but not limited to) jump ropes, clotheslines, pet leashes, cables, and
 chains. These may become strangulation hazards.
- To hold on to swings and climbers with both hands.
- To slide feet first, never head first.
- To watch for other children while swinging or playing near the swing set.

To also insure SAFE PLAY adults must:

- Limit climbing and swinging heights to each child's ability.
- Verify that suspended climbing ropes are secured at both ends.
- Verify that suspended climbing ropes cannot be looped back on themselves.
- Dress children appropriately for play. Use well-fitted shoes that do not have slippery soles.
- Avoid ponchos, scarves, hoods, loose fitting clothing, neckties, and any clothing with a drawstring.
 Serious injury could result should any part of the children's clothing become entangled in the swing set.
- Do not allow children to play wearing helmets.
- Remember that children are inventive. When they develop games that are unsafe, be alert and change the rules.

Weight limits for Treefrogs Swingsets

Fort Platform: 800 Lbs. Total Weight. Swing Belts: 175 Lbs.

<u>Trapeze</u>: 125 Lbs. <u>Full Bucket Swing</u>: 50 Lbs.

<u>Toddler Bucket Swing</u>: 50 Lbs. <u>Tire Swing</u>: 125 Lbs. Total Weight

Rope Ladder: 75 Lbs. Rock Wall: 150 Lbs.

All Slides: 125 Lbs.

Tree Frogs recommends that the weight limits for all components must not be exceeded.

Failure to adhere to these and other safety guidelines could result in damage to the swing set.

and/or injury to the users.

CONSUMER INFORMATION SHEET FOR PLAYGROUND SURFACING MATERIALS

The U.S. Consumer Product Safety Commission (CPSC) estimates that about 100,000 playground equipment related injuries resulting from falls to the ground surface are treated annually in U.S. hospital emergency rooms. Injuries involving this hazard pattern tend to be among the most serious of all playground injuries, and have the potential to be fatal, particularly when the injury is to the head. The surface under and around playground equipment can be a major factor in determining the injury-causing potential of a fall. It is self-evident that a fall onto a shock-absorbing surface is less likely to cause a serious injury than a fall onto a hard surface. However, it should be recognized that some injuries from falls will occur no matter what playground surfacing material is used.

Playground equipment should never be placed on hard surfaces such as concrete or asphalt. Grass may appear to be acceptable, but can turn to hard packed earth in areas of high traffic. Shredded bark mulch, wood chips, or fine gravel are considered to be acceptable shock absorbing surfaces when installed and maintained at a sufficient depth under and around play equipment.

MATERIAL	UNCO	MPRESSE	D DEPTH	COMPRESSED DEPTH
	6 Inch	9 Inch	12 Inch	9 inch
Wood Chips	7	10	11	10
Double Shredded Bark Mulch	6	10	11	7
Engineered Wood Fibers	6	7	>12	6
Fine Sand	5	5	9	5
Coarse Sand	5	5	6	4
Fine Gravel	6	7	10	6
Medium Gravel	5	5	6	5

10-12

Shredded Tires**

TABLE 1 -CRITICAL HEIGHTS (in feet) OF TESTED MATERIAL

N/A

N/A

Table 1 should be read as follows: If, for example, uncompressed wood chips are used at a minimum of 6 inches, the Critical Height is 7 feet. If 9 inches of uncompressed wood chips are used, the Critical Height is 10 feet. It should be noted that, for some materials, the Critical Height decreases when the material is compressed. It is recommended that a shock absorbing material should extend a minimum of 6 feet in all directions from the perimeter of stationary equipment such as climbers and slides. However, because children may deliberately jump from a moving swing, the shock absorbing material should extend in the front and rear of a swing a minimum distance of 2 times the height of the pivot point measured from a point directly beneath the pivot on the supporting structure.

This information is intended to assist in comparing the relative shock-absorbing properties of various materials. No particular material is recommended over another. However, each material is only effective when properly maintained. Materials should be checked periodically and replenished to maintain correct depth as determined necessary for your equipment. The choice of a material depends on the type and height of the playground equipment, the availability in your area, and its cost.

This information has been extracted from the CPSC publications "Playground Surfacing-Technical Information Guide" and "Handbook for Public Playground Safety." Copies of these reports can be obtained by sending a postcard to:

Office of Public Affairs
U.S. Consumer Product Safety Commission
Washington, D.C. 20207

Toll-free Hotline: 1-800-638-2772 or at http://www.cpsc.gov

^{**} This is data from tests conducted by independent testing laboratories on a 6 inch depth of uncompressed shredded tire samples produced by four manufacturers. The test reported critical heights, which varied from 10 feet to greater than 12 feet. It is recommended that persons seeking to install shredded tires as a protective surface request test data from the supplier showing the critical height of the material when it was tested in accordance with ASTM F1292.

2018 TREE FROGS Limited Lifetime Warranty

Limited 10-Year Warranty, Limited 5-Year Warranty

Tree Frogs Warranties all Jaguar Playcenter Series, Bengal Forts Series, MegaDeck Fort Series Redwood components and Cedar components against structural failure due to warping, wood rot, insect infestation (excluding Carpenter Bees) or decay for the period of 10 Years from the date of original purchase. This warranty does not cover cracks, fissions, checks, fading, knots and weathering that are normal natural characteristics of wood, that do not affect the structural integrity of the product. The Redwood and Cedar components warranty is extended to a Limited Lifetime Warranty to the original owner upon registering this warranty within 90 days of purchase at www.treefrogsswingsets.com.

Tree Frogs Warranties all Parrot Island Fort Series, Parrot Island Playcenter Series, Rainforest Cottage Series Cedar components against structural failure due to warping, wood rot, insect infestation (excluding Carpenter Bees) or decay for a period of 10 Years from the date of original purchase. This warranty does not cover cracks, fissions, checks, fading, knots and weathering that are normal natural characteristics of wood, that do not affect the structural integrity of the product.

Tree Frogs Warranties all Toucan Fort Series, Toucan Playcenter Series, Orangutan Fort Series, Stand Alone Swings Cedar components against structural failure due to warping, wood rot, insect infestation (excluding Carpenter Bees) or decay for a period of 5 Years from the date of original purchase. This warranty does not cover cracks, fissions, checks, fading, knots and weathering that are normal natural characteristics of wood, that do not affect the structural integrity of the product.

In addition, a 10-Year Limited Warranty applies to all roto-molded slides, ductile iron swing hangers, tire swivels, metal climbing rungs and swing beam brackets against failure due to rust or failure in defect in material. Surface rust, fading, weathering, cracks/chips in coatings and corrosion that do not affect structural integrity are not covered by this warranty. Furthermore, a 5-Year Limited Warranty applies to all components & accessories including all swings, chain ladders, gliders, handles, brackets, bubble panels, tarps, steering/ships wheels, telescopes, binoculars, buoy ball, blow molded slides and disc seat that are not covered under the 10-Year Warranty to be free from defects in material and workmanship. Surface rust, fading, weathering, cracks/chips in coatings and corrosion that do not affect structural integrity are not covered by this warranty.

And for a period of 1-Year Tree Frogs warranties all ropes, structural foam molded slides to be free of defects in material and workmanship. Fading is not considered a defect and may occur with seasonal and geographical conditions.

**10-Year Warranty Exclusion: Toucan Fort Series, Toucan Playcenter Series, Orangutan Series, Stand Alone Swings (Limite 5Yr/5Yr/1Yr WARRANTY).

This warranty is limited to a repair or replacement of the defective part. Product covered under this warranty will be shipped at the customer's expense. Tree Frogs is not responsible for any expense associated with freight, or delivery and installation of the warranted part(s). Tree Frogs reserves the right to inspect all warranty claim parts for which a claim has been made.

This limited warranty applies only to the original retail purchaser and for residential use only, non-residential use voids warranty. These warranties void when product is transferred or sold or no longer in possession by original owner. A copy of the original invoice must be presented to initiate warranty claim. This limited warranty does not cover damage from abuse, acts of God, vandalism, maintenance guideline neglect, alterations, normal wear & tear, use other than residential, unauthorized modification, damage due to moving of product or improper installation and or use. Any modification could damage the structural integrity of the play system and voids all warranties.

This warranty is exclusive and expressly in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for use. Tree Frogs does not assume, or authorize any person to assume for us, any other liability in connection with the sale of our products.

This warranty gives you specific legal rights, and you also may have other rights that vary from state to state. Register your play system's warranty at www.treefrogsswingsets.com.

Tree Frogs reserves the right at any time to change product specifications or substitute similar components.

See your instruction manual for guidelines on regular maintenance. http://treefrogsshowrooms.com/installation-manuals/. Your child's play system & perimeter play zone should be inspected regularly for any wear & safety hazards.

Extended Monkey Bar (032)	Description	QTY.
	(CC-220) 032-1 31 1/4" Monkey Bar Bottom	1
	(CC-136) 032-2 26 1/2" Step	4
	(CC-149) 032-3 19" Left Gusset	1
	(CC-148) 032-4 19" Right Gusset	1
	(CC-190) 032-5 16" Left MB Gusset	1
	(CC-191) 032-6 16" Right MB Gusset	1
	(CC-193) 032-7 103" Left Support Leg	1

Extended Monkey Bar (032)	Description	QTY.
	(CC-192) 032-8 103" Right Support Leg	1
	032-9 119 1/2" (R) Monkey Bar Overhead	1
	032-10 119 1/2" (L) Monkey Bar Overhead	1

EXTENDED MONKEY BAR -032-HWR-BAG

INSTALLER NOTE: (YOU MUST ASSEMBLE THIS PRODUCT IN ACCORDANCE WITH THESE ASSEMBLY INSTRUCTIONS. WHEN COMPLETE GIVE MANUAL TO OWNER.)

MB-2

MB-1 1/2" x 7" Cariage Bolt 1/2" Acorn Nut Plated QTY. 4 QTY. 4

MB-3 1/2" Hex Nut QTY. 4




MB-4 3/8" x 10 Hex Bolt QTY. 1



EXTENDED MONKEY BAR -032-HWR-BAG

INSTALLER NOTE: (YOU MUST ASSEMBLE THIS PRODUCT IN ACCORDANCE WITH THESE ASSEMBLY INSTRUCTIONS. WHEN COMPLETE GIVE MANUAL TO OWNER.)

MB-5 1/2 x 9" Hex Bolt QTY. 1




MB-6 1/4" x 3" Hex Lag Screw QTY. 4




MB-7 1/4" x 4 1/2" Hex Lag Screw QTY. 16



MB-8 3/8" x 3 1/2" Hex Lag Screw QTY. 12




MB-9 3/8" x 5" Hex Lag Screw QTY. 2



EXTENDED MONKEY BAR -032-HWR-BAG

INSTALLER NOTE: (YOU MUST ASSEMBLE THIS PRODUCT IN ACCORDANCE WITH THESE ASSEMBLY INSTRUCTIONS. WHEN COMPLETE GIVE MANUAL TO OWNER.)




Extended Monkey Bar-032-HWA-SB	Description	QTY.
	032-A 1 1/4" x 22 1/4" PlayGrip Tube	8
	032-B PlayGrip Ladder Handle	2

Monkey Bar Support - Sub Assemblies

PARTS NEEDED

HARDWARE NEEDED

CC-220- Monkey Bar Bottom- CC-136- Step- CC-192- Right Support Leg- CC-193- Left Support Leg-	(1) (4) (1) (1)	MB-7- 1/4"x4 1/2" Hex Lag Screw ZP- MB-13- 1/4" Uss Flatwasher ZP- MB-10- #14 x 2" Pan Phillip T/S ZP-	(16) (16) (4)	MB-9 3/8" x 5" Hex Lag Screw ZP- MB-14 3/8" Uss Flatwasher ZP- MB-13 1/4" Uss Flatwasher ZP-	(4) (4) (4)
032-B- PlayGrip Ladder Handle-	(2)				



Extended Monkey Bar Overhead Extended Monkey Bar Assembly

PARTS NEEDED

(1) MB-11- 2" Metal Tap Screw-

- 032-9- (R) Monkey Bar Overhead-032-8- (L) Monkey Bar Overhead-032-A 1 1/4"Diax 16 ga x22" PlayGrip Tube-
- (1) MB-16- 3/4" USS Flatwasher-(6) MB-12- 1/2" Split Lockwasher-
 - MB-1- 1/2" Acorn Nut Plated-
- (2) MB-15- 1/2" USS Flatwasher-
- (2) MB-3- 1/2" Hex Nut-

MB-2- 1/2" x 7" Carriage Bolt-


(2) (2)

(2)

(2)

HARDWARE NEEDED

(12)



Monkey Bar Assembly

PARTS NEEDED

Monkey Bar Overhead Assembly (1)

Support Assembly (1)

CC-190 Left MB Gusset (1)

CC-191 Right MB Gusset (1)

HARDWARE NEEDED

MB-1- 1/2"-13 Acorn Nut Plated-

MB-8- 3/8" x 3 1/2" Hex Lag Screw-


MB-12- 1/2" Split Lockwasher-

MB-15- 1/2" Uss Flatwasher-

- (2) MB-2- 1/2"-13 x 7" Carriage Bolt-
- (8) MB-3- 1/2"-13 Hex Nut- (2)

(2)

- (2) MB-14- 3/8" Uss Flatwasher- (8)
- (2) MB-16- 3/4" Uss Flatwasher- (2)



MB-15 MB-12 MB-15 MB-15 MB-3

Grab the Monkey Bar Overhead at the rung that is in the center and pull up scissoring the Monkey Bar Overhead and the Monkey Bar Support. Now facing the Monkey Bar Support place your Left Monkey Bar Gusset on the inside of the board and push up until it touches the Monkey Bar Overhead. Have your helper pull out on the Monkey Bar Support until the notches on the Left Monkey Bar Gusset are flat against the Monkey Bar Support and the Monkey Bar Overhead. **Be careful and do not let the assembly scissor back down as this can cause an injury or damage your Monkey Bars.** Place a 3/8" Flatwasher over a 3/8" x 3 1/2" Hex Lag Screw and attach the Left Monkey Bar Gusset to the Monkey Bar Overhead and Monkey Bar Support Ladder. Repeat this process on the right side. Now tighten the 1/2" Hex Nuts, put on the 1/2" Acorn Nut and lightly tighten. Do not over tighten.

5.8 Jaguar Fort Monkey Bar Assembly

5.8 Jaguar Playcenter Monkey Bar Assembly


PARTS NEEDED

Monkey Bar Assembly CC-149 Left Gusset (1) CC-148 Right Gusset (1)


MB-1- 1/2"-13 Acorn Nut Plated-	(2)	MB-2- 1/2"-13 x 7" Carriage Bolt-	(2)
MB-3- 1/2"-13 Hex Nut-	(2)	MB-5- 1/2"-16 x 9" Hex Bolt-	(1)
MB-8- 3/8" x 3 1/2" Hex Lag Screw-	(4)	MB-12- 1/2" Split Lockwasher-	(2)
MB-14- 3/8" Uss Flatwasher-	(4)	MB-15- 1/2" Uss Flatwasher-	(2)
MB-16- 3/4" Uss Flatwasher-	(1)	A-2- 1/2"-13 Acorn Nut Plated-	(1)
C- 1/2"-13 Hex Nut-	(1)	M- 1/2" Split Lockwasher-	(1)
P- 1/2" Uss Flatwasher-	(1)		

HARDWARE NEEDED

On the other side place a 3/4" Flatwasher over a 1/2" x 7" Carriage Bolt and then insert thru the hole into the countersunk hole in the Monkey Bar Overhead. Place a 1/2" Washer, 1/2" Lockwasher over the 1/2" x 7" Carriage Bolt end inside the Monkey Bar Overhead. Thread the 1/2" Hex Nut on to the 1/2" x 7" Carriage Bolt. Now tighten the 1/2" Hex Nuts, put on the 1/2" Acorn Nut and lightly tighten. Do not over tighten. Place Left Gusset Bracket and attach with 2 - 3/8" x 3 1/2" Hex Lag Screw with 3/8" Flatwashers on them.



This step is only if you purchased a 5 or 5.8 Fort. Line up Monkey Bar Overhead countersunk holes with the holes below your 6 Hole Facia. Place a 3/4" Flatwasher over a 1/2" x 7" Carriage Bolt and then insert thru the hole into the countersunk hole in the Monkey Bar Overhead. Place a 1/2" Washer, 1/2" Lockwasher over the 1/2" x 7" Carriage Bolt end inside the Monkey Bar Overhead. Thread the 1/2" Hex Nut on to the 1/2" x 7" Carriage Bolt. Repeat this process on the other side. Now tighten the 1/2" Hex Nuts, put on the 1/2" Acorn Nut and lightly tighten. Do not over tighten. Place Left Gusset Bracket and attach with 2 - 3/8" x 3 1/2" Hex Lag Screw with 3/8" Flatwashers on them. Repeat this process for the Right Gusset Bracket on other side.



Remove the $1/2" \times 7"$ Carriage Bolt and Hardware from the Corner Post. Then line up Monkey Bar Overhead countersunk holes with the holes in the Playcenter as seen above. Place a 1/2" Washer over the $1/2" \times 9"$ Hex Bolt and then insert thru the Front Beam, then thru the Corner Post, and into the countersunk hole in the Monkey Bar Overhead. Place a 1/2" Washer, 1/2" Lockwasher over the $1/2" \times 9"$ Hex Bolt end inside the Monkey Bar Overhead. Thread the 1/2" Hex Nut on to the $1/2" \times 9"$ Hex Bolt. Place Right Gusset Bracket and attach with $2 - 3/8" \times 3 1/2"$ Hex Lag Screw with 3/8" Flatwashers on them.

6.5 & 7.5 Monkey Bar Assembly

HARDWARE NEEDED

MB-1- 1/2"-13 Acorn Nut Plated-

(2) MB-2- 1/2"-13 x 7" Cariage Bolt-

MB-3- 1/2"-13 Hex Nut-


(2) MB-12- 1/2" Split Lockwasher-

MB-15- 1/2" Uss Flatwasher-

(2) MB-16- 3/4" Uss Flatwasher-




(2)



Set the Monkey Bar overhead on the deck(Fort) or line up the bottom of the Monkey Bar Overhead with the top of the Deck(Playcenter) and insert Monkey Bar Overhead in between the Corner Post and the Center Post. Make sure the ends of the Monkey Bar Overhead is flush with the inside of Corner Post and Center Post and then drill (see Figure 2) thru the Monkey Bar Overhead countersinks thru the Corner Post and Center Post. (On a playcenter swingset you will need to remove the Gusset on the Corner Post prior to drilling and then put the Gusset back on once all the Hardware is installed and tightened.) Place a 3/4" Flatwasher over a 1/2" x 7" Carriage Bolt and then insert thru the hole into the countersunk hole in the Monkey Bar Overhead. Place a 1/2" Washer, 1/2" Lockwasher over the 1/2" x 7" Carriage Bolt end inside the Monkey Bar Overhead. Thread the 1/2" Hex Nut on to the 1/2"x 7" Carriage Bolt. Repeat this process on the other side. Now tighten the 1/2" Hex Nuts, put on the 1/2" Acorn Nut and lightly tighten. Do not over tighten.

Extended Loft Installation Manual





4465 West Sam Houston Parkway N. Houston, Texas 77041 WWW.TREEFROGSSHOWROOMS.COM

Sections

Section 1: Cover & Liability Info

Section 2: Product Parts

Section 3: Sub-Assemblies

Section 4: Main Assebmly

Section 5: Roof Options

© 2018 KID STRUCTURES INC.

IMPORTANT - PLEASE READ

As fresh lumber acclimates to its new environment, the natural tendencies of the tree can show itself in the form of checks, or "cracks" in the lumber. In almost all cases this is normal and it will not affect the structural integrity of your play set.

Cosmetic defects that do not affect the structural integrity of the product, or natural defects of wood such as warping, checking or any other physical properties of wood that do not present a safety hazard, are not covered by this warranty.

Defects that develop because the product is exposed to extreme climate conditions are not covered by this warranty. Defects that develop as a result of faulty or improper installation of the product are also not covered by this warranty.

Most cracks are not warrantable, however if you believe that the integrity of your play set is compromised by this natural occurrence, please contact the Tree Frogs Swing Set Dealer that you purchased your swing set from.

We appreciate your purchase and know that you will enjoy your play system for many years to come.

Tools Needed for Assembly

Tape Measure 24" Level Angle Square

Phillips Screw Driver 3/8" Cordless Drill or Electric Drill 3/8" Drive Ratchet or Electric Impact Gun

Claw Hammeror Rubber Mallet Pliers or Vise Grips 7/16" Deep Well Socket

9/16" Deep Well Socket 3/4" Deep Well Socket 1/8", 1/4", and 9/16" Drill Bits

Phillips Head Screw Bits An Adult with two Adult Helpers

Please familiarize yourself with the install manual, parts/components and general construction process of your new swing set before getting started. Approximate assembly time: 6 to 8 hours. 6 foot unobstructed safety perimeter around swingset recommended.

Pre-Assembly Hints

- Depending on your experience, assembly of our play sets can take as little as 6 hours up to 24 hours, depending on size, after inventory of parts; therefore, we recommend you set aside a full two days for assembly.
- Identify all of the parts for your play set. Empty each box and lay out boards so you can see each part. Your instruction book will
 have detailed drawings that will make it easy for you to recognize individual parts. Keep all hardware and metal parts separate
 from wooden pieces.
- After everything is laid out, check carefully to ensure all parts are present. Make sure there are no broken boards.
- Find an area to sort your hardware. It is best to open the hardware on a solid surface so that you do not lose any pieces in the grass.
 - This will save time and familiarize you with all the different pieces in the hardware bag.
 - **Important note: Wood has some natural defects such as knots, surface cracks, etc... We reject parts that are structurally defective. We use a high quality lumber in our structures; however, you should inspect each part for splinters or rough spots and sand them smooth to prevent injury.**
- After familiarizing yourself with all of the components, read all instructions thoroughly. Reading instructions after you have studied the parts will help you understand more clearly the installation process, and help to eliminate unnecessary mistakes.
- Pay close attention to the diameter and length of each bolt and screw.
- Never tighten hardware completely at first. It helps to have some adjustment for bolt alignment while you are attaching parts together. After everything is square, tighten each joint.
- After the main unit is assembled it is critical that the floor is level and square. If the main frame is not level, the walls and floor will be out of square.
- After you complete installation, make sure every bolt, screw, and nut is tight, and every board is secure. Wood will expand and contract with the seasons.
- Place the set on level ground, not less than 6ft from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.
- All 1/4" and 3/8" lag bolts must have pre-drilled holes 1-1/2" to 2" deep. Use a 1/8" drill bit for the 1/4" lag bolts and 1/4" drill bit for 3/8" lag bolts. Use pre-drilled holes in facias as a reference for placing lag bolt pilot holes.
- If a board lifts or rises causing a gap between boards when running in lag bolts or screws, back out the screw or lag bolt and press or apply pressure (but not enough to crack or break board) while re¬running in the lag bolt or screw in the same hole.
- Do not over tighten bolts, lag bolts or screws. You can damage boards, break hardware, and/or strip out the hardware.
- When using hammer do not beat on the hardware, but gently tap it in. Never beat on the wood as it will leave marks.

Leveling Your Swing Set During Assembly

- Complete the steps which will be the basic frame of the fort {i.e. four corner posts with base (sand box boards) and deck supports}
- Position in the most level area chosen for the play set, keeping in mind the location and size of the swing beam, ladder, slides, etc. that extend off the fort.
- Once the frame is in the final position, check for vertical and horizontal levelness to determine which side(s) will need to be dug into the ground to level the play set.
- With a shovel, score the ground around the outside edges of the sandbox boards on the 'high' side of the fort. This is the area that will be dug in. Make sure to score deep enough; the scored lines will be your digging template.
- Push the frame off and away from the scored area, far enough to dig and remove dirt to reach the appropriate depth.
- Dig a channel along the scored line(s) for the base of the fort (corner post and sandbox boards) to rest into. Dig the channel(s) to the same level depth. The bottom of the channel(s) should be level to each other so your frame doesn't teeter or rock because the channel(s) are uneven.
- Once you have removed enough grass and dirt, slide/push the frame into the channel(s). Place a level on the vertical and horizontal boards of the frame to determine if enough soil, or too much, was removed.
- Repeat this process until the basic frame is plumb and level and in its final position before completing the rest of the assembly.
- Measure to make sure fort is square.

^{**} Important: if you require a channel depth of more than 6",then we recommend you have your play set area professionally graded before completing assembly. **

Choosing A Location For Your Playset

When choosing a location for your swing set, always keep your child or children's safety in mind. Here are some recommendations to help you locate and install a safe play area.

- This play set is designed for the use of 4 occupants who have a combined weight not exceeding 800 pounds on the elevated floor; 3 occupants who have a combined weight of 525 pounds on the swing area; for a total Unit capacity of 5 occupants who have a combined weight of 1325. (this weight is not including the picnic table area)
- On-site adult supervision is required.
- The swing set should be located on level ground. The stationary components such as ladders and slides are required to be a minimum of six feet from any structure or obstruction such as a fence, garage, house, tree, overhanging branches, electrical wires, clotheslines, etc. Any swinging equipment is also required to be a minimum distance twice the height of the swing beam away from these obstructions or structures as well. The swing set should be located a safe distance from any water hazards, such as a lake, river, bayou, swimming pool, etc.
- Do not install this residential swing set in a commercial setting. This swing set is not manufactured for commercial usage and will void all warranties. Tree Frogs Wooden Swing Set Factory is not responsible for any damages or injuries resulting from this swing set being used in a commercial setting.
- Never install this swing set indoors; or over concrete, asphalt, packed earth, grass, carpet or any other hard surface. A fall onto a hard surface can result in serious or fatal injury.
- The U.S. Consumer Product Safety Commission (CPSC) recommends that you install and maintain a resilient surface under your swing set. The CPSC's Consumer Information Sheet for Playground Surfacing Materials is on the next page. A resilient surface, should be installed after the swing set has been completely assembled according to these instructions. The swing set must rest on solid ground. Please note that this swing set has a maximum fall height of 7'.

Maintaining Your Swing Set

Here are some maintenance tips required to insure safe play on your swing set for years of fun.

- At the beginning of each usage season and every two weeks during, check: nuts and bolts and tighten as needed, swing seats, chains, ladders, slides, rope and wood components for sign of deterioration and replace if necessary.
- On a yearly basis, we recommend that you coat your swing set with a sealant or preservative. You may also wantto spot sand any areas prior to sealing.
- ** Special note: Although we recommend that you reseal your swing set annually, you may have to touch up the high traffic areas and/or areas that have a high exposure to direct sunlight.**
- Be sure that the sealant you select is non-toxic and child safe. Your local Tree Frogs Wooden Swing Set Factory dealer may offer a complete power wash and reseal and maintenance program.
- Do not use line trimmers or "weed eaters" around your swing set. The line will remove both paint and wood from uprights and base pieces. Any damage resulting from this type of abuse is not covered under our limited warranty.
- Remove plastic swing seats and take in doors or do not use when temperature drops below 0°F.

Please keep this install manual for future reference.

To insure SAFE PLAY adults must teach children:

- Not to walk close to, in front of, behind, or between moving items.
- Not to swing empty swing seats.
- Not to swing sideways into the path of adjacent swings.
- Not to use the swing set in a manner other than that for which it is intended.
- Not to get off the equipment while it is in motion.
- Not to jump off the tower.
- Not to stand in the swing seats.
- Not to swing so high that chains become slack, or above the height of the swing support.
- Not to jump on a slide.
- Not to climb on top of the swing support.
- Not to attach to the swing set any item that is not specifically designed for use with the
 equipment, such as (but not limited to) jump ropes, clotheslines, pet leashes, cables, and
 chains. These may become strangulation hazards.
- To hold on to swings and climbers with both hands.
- To slide feet first, never head first.
- To watch for other children while swinging or playing near the swing set.

To also insure SAFE PLAY adults must:

- Limit climbing and swinging heights to each child's ability.
- Verify that suspended climbing ropes are secured at both ends.
- Verify that suspended climbing ropes cannot be looped back on themselves.
- Dress children appropriately for play. Use well-fitted shoes that do not have slippery soles.
- Avoid ponchos, scarves, hoods, loose fitting clothing, neckties, and any clothing with a drawstring.
 Serious injury could result should any part of the children's clothing become entangled in the swing set.
- Do not allow children to play wearing helmets.
- Remember that children are inventive. When they develop games that are unsafe, be alert and change the rules.

Weight limits for Treefrogs Swingsets

Fort Platform: 800 Lbs. Total Weight. Swing Belts: 175 Lbs.

<u>Trapeze</u>: 125 Lbs. <u>Full Bucket Swing</u>: 50 Lbs.

<u>Toddler Bucket Swing</u>: 50 Lbs. <u>Tire Swing</u>: 125 Lbs. Total Weight

Rope Ladder: 75 Lbs. Rock Wall: 150 Lbs.

All Slides: 125 Lbs.

Tree Frogs recommends that the weight limits for all components must not be exceeded.

Failure to adhere to these and other safety guidelines could result in damage to the swing set.

and/or injury to the users.

CONSUMER INFORMATION SHEET FOR PLAYGROUND SURFACING MATERIALS

The U.S. Consumer Product Safety Commission (CPSC) estimates that about 100,000 playground equipment related injuries resulting from falls to the ground surface are treated annually in U.S. hospital emergency rooms. Injuries involving this hazard pattern tend to be among the most serious of all playground injuries, and have the potential to be fatal, particularly when the injury is to the head. The surface under and around playground equipment can be a major factor in determining the injury-causing potential of a fall. It is self-evident that a fall onto a shock-absorbing surface is less likely to cause a serious injury than a fall onto a hard surface. However, it should be recognized that some injuries from falls will occur no matter what playground surfacing material is used.

Playground equipment should never be placed on hard surfaces such as concrete or asphalt. Grass may appear to be acceptable, but can turn to hard packed earth in areas of high traffic. Shredded bark mulch, wood chips, or fine gravel are considered to be acceptable shock absorbing surfaces when installed and maintained at a sufficient depth under and around play equipment.

MATERIAL	UNCO	MPRESSE	D DEPTH	COMPRESSED DEPTH
	6 Inch	9 Inch	12 Inch	9 inch
Wood Chips	7	10	11	10
Double Shredded Bark Mulch	6	10	11	7
Engineered Wood Fibers	6	7	>12	6
Fine Sand	5	5	9	5
Coarse Sand	5	5	6	4
Fine Gravel	6	7	10	6
Medium Gravel	5	5	6	5

10-12

Shredded Tires**

TABLE 1 -CRITICAL HEIGHTS (in feet) OF TESTED MATERIAL

N/A

N/A

Table 1 should be read as follows: If, for example, uncompressed wood chips are used at a minimum of 6 inches, the Critical Height is 7 feet. If 9 inches of uncompressed wood chips are used, the Critical Height is 10 feet. It should be noted that, for some materials, the Critical Height decreases when the material is compressed. It is recommended that a shock absorbing material should extend a minimum of 6 feet in all directions from the perimeter of stationary equipment such as climbers and slides. However, because children may deliberately jump from a moving swing, the shock absorbing material should extend in the front and rear of a swing a minimum distance of 2 times the height of the pivot point measured from a point directly beneath the pivot on the supporting structure.

This information is intended to assist in comparing the relative shock-absorbing properties of various materials. No particular material is recommended over another. However, each material is only effective when properly maintained. Materials should be checked periodically and replenished to maintain correct depth as determined necessary for your equipment. The choice of a material depends on the type and height of the playground equipment, the availability in your area, and its cost.

This information has been extracted from the CPSC publications "Playground Surfacing-Technical Information Guide" and "Handbook for Public Playground Safety." Copies of these reports can be obtained by sending a postcard to:

Office of Public Affairs
U.S. Consumer Product Safety Commission
Washington, D.C. 20207

Toll-free Hotline: 1-800-638-2772 or at http://www.cpsc.gov

^{**} This is data from tests conducted by independent testing laboratories on a 6 inch depth of uncompressed shredded tire samples produced by four manufacturers. The test reported critical heights, which varied from 10 feet to greater than 12 feet. It is recommended that persons seeking to install shredded tires as a protective surface request test data from the supplier showing the critical height of the material when it was tested in accordance with ASTM F1292.

2018 TREE FROGS Limited Lifetime Warranty

Limited 10-Year Warranty, Limited 5-Year Warranty

Tree Frogs Warranties all Jaguar Playcenter Series, Bengal Forts Series, MegaDeck Fort Series Redwood components and Cedar components against structural failure due to warping, wood rot, insect infestation (excluding Carpenter Bees) or decay for the period of 10 Years from the date of original purchase. This warranty does not cover cracks, fissions, checks, fading, knots and weathering that are normal natural characteristics of wood, that do not affect the structural integrity of the product. The Redwood and Cedar components warranty is extended to a Limited Lifetime Warranty to the original owner upon registering this warranty within 90 days of purchase at www.treefrogsswingsets.com.

Tree Frogs Warranties all Parrot Island Fort Series, Parrot Island Playcenter Series, Rainforest Cottage Series Cedar components against structural failure due to warping, wood rot, insect infestation (excluding Carpenter Bees) or decay for a period of 10 Years from the date of original purchase. This warranty does not cover cracks, fissions, checks, fading, knots and weathering that are normal natural characteristics of wood, that do not affect the structural integrity of the product.

Tree Frogs Warranties all Toucan Fort Series, Toucan Playcenter Series, Orangutan Fort Series, Stand Alone Swings Cedar components against structural failure due to warping, wood rot, insect infestation (excluding Carpenter Bees) or decay for a period of 5 Years from the date of original purchase. This warranty does not cover cracks, fissions, checks, fading, knots and weathering that are normal natural characteristics of wood, that do not affect the structural integrity of the product.

In addition, a 10-Year Limited Warranty applies to all roto-molded slides, ductile iron swing hangers, tire swivels, metal climbing rungs and swing beam brackets against failure due to rust or failure in defect in material. Surface rust, fading, weathering, cracks/chips in coatings and corrosion that do not affect structural integrity are not covered by this warranty. Furthermore, a 5-Year Limited Warranty applies to all components & accessories including all swings, chain ladders, gliders, handles, brackets, bubble panels, tarps, steering/ships wheels, telescopes, binoculars, buoy ball, blow molded slides and disc seat that are not covered under the 10-Year Warranty to be free from defects in material and workmanship. Surface rust, fading, weathering, cracks/chips in coatings and corrosion that do not affect structural integrity are not covered by this warranty.

And for a period of 1-Year Tree Frogs warranties all ropes, structural foam molded slides to be free of defects in material and workmanship. Fading is not considered a defect and may occur with seasonal and geographical conditions.

**10-Year Warranty Exclusion: Toucan Fort Series, Toucan Playcenter Series, Orangutan Series, Stand Alone Swings (Limite 5Yr/5Yr/1Yr WARRANTY).

This warranty is limited to a repair or replacement of the defective part. Product covered under this warranty will be shipped at the customer's expense. Tree Frogs is not responsible for any expense associated with freight, or delivery and installation of the warranted part(s). Tree Frogs reserves the right to inspect all warranty claim parts for which a claim has been made.

This limited warranty applies only to the original retail purchaser and for residential use only, non-residential use voids warranty. These warranties void when product is transferred or sold or no longer in possession by original owner. A copy of the original invoice must be presented to initiate warranty claim. This limited warranty does not cover damage from abuse, acts of God, vandalism, maintenance guideline neglect, alterations, normal wear & tear, use other than residential, unauthorized modification, damage due to moving of product or improper installation and or use. Any modification could damage the structural integrity of the play system and voids all warranties.

This warranty is exclusive and expressly in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for use. Tree Frogs does not assume, or authorize any person to assume for us, any other liability in connection with the sale of our products.

This warranty gives you specific legal rights, and you also may have other rights that vary from state to state. Register your play system's warranty at www.treefrogsswingsets.com.

Tree Frogs reserves the right at any time to change product specifications or substitute similar components.

See your instruction manual for guidelines on regular maintenance. http://treefrogsshowrooms.com/installation-manuals/. Your child's play system & perimeter play zone should be inspected regularly for any wear & safety hazards.

KSI-046 Extended Loft Lumber	Description	QTY.
0	(CC-021) 046-1 28" Spiral Slide Filler	2
	046-2 89 1/4" 4- Hole Facia	2
	(CC-062) 046-3 32" Entrapment Facia	1
	(CC-088) 046-4 27 1/2" Rail Spindle	30
	(CC-099) 046-5 25" Rail Top	6
	(CC-101) 046-6 25" Universal Filler	5
	(CC-102) 046-7 25" Deck Runner	6

KSI-046 Extended Loft Lumber	Description	QTY.
	(CC-100) 046-8 25" Rail Bottom	6
	(CC-109) 046-9 32" Deck Board	3
	(CC-112) 046-10 53" Top Joist	2
	046-11 89 1/4" Tarp Center	1
	046-12 92" Tarp Side Facia	2
	(CC-138) 046-13 25" Entrapment Board	1
	(CC-139) 046-14 32" Deck Board	12


KSI-046 Extended Loft Lumber	Description	QTY.
	(CC-140) 046-15 32" 6- Hole Facia	2
	046-16 89 1/4" 8- Hole Facia	2
	(CC-141) 046-17 25" Entrapment Board	1
	(CC-181) 046-18 32 5/16" Tarp Upright	2
	(CC-180) 046-19 41" Center Upright	4
	(CC-179) 046-20 46" Corner Post	4
	(CC-194) 046-21 25" Entrapment Block	2

KSI-047 Extended Loft Wood Roof Lumber	Description	QTY.
	(CC-197) 047-1 6 5/16" Short Fan Board	4
	(CC-006) 047-2 8 7/16" Center Fan Board	2
	(CC-022) 047-3 28 3/4" Bottom Fan Board	2
	(CC-055) 047-4 11 1/16" Peak Support	4
	(CC-056) 047-5 11 7/16" Fan Cap	2
	(CC-110) 047-6 39 3/8" Wood Roof Support	8
	047-7 22" Center Wood Roof Support	4

KSI-047 Extended Loft Wood Roof Lumber	Description	QTY.
	047-8 92" Wood Roof Board	18


EXTENDED LOFT - 047- HWR-BAG

INSTALLER NOTE: (YOU MUST ASSEMBLE THIS PRODUCT IN ACCORDANCE WITH THESE ASSEMBLY INSTRUCTIONS. WHEN COMPLETE GIVE MANUAL TO OWNER.)



KSI-047 EXTENDED LOFT WOOD ROOF HARDWARE

INSTALLER NOTE: (YOU MUST ASSEMBLE THIS PRODUCT IN ACCORDANCE WITH THESE ASSEMBLY INSTRUCTIONS. WHEN COMPLETE GIVE MANUAL TO OWNER.)



KSI-046 Extended Loft Accessories	Description	QTY.
	046-A Bubble Panel	1
	046-B Binocul;ar	1

Extended Loft- Sub Assemblies

(4) (4)

(8)

PARTS NEEDED

CC-088- Rail Spindle-

CC-100- Rail Bottom-

CC-109- Deck Board-


- (20) CC-099- Universal Rail Top-
- (4) CC-102- Deck Runner-
- 2) CC-139- Deck Board-


HARDWARE NEEDED

B- #8 x 2 1/2" Coated Deck Screw-

(180)

Make 3 of these Assemblies





Extended Loft -Sub Assemblies


PARTS NEEDED

HARDWARE NEEDED

CC-062- Entrapment Board-CC-140- 6-Hole Facia-CC-194- Entrapment Block-

- CC-112- Top Joist-(1)
- (2) CC-179- Corner Post-
- (2) 046-A- Bubble Panel-

- A-6- 3/8" USS Flatwasher-(2)
 - (24)(20)
- A-3- 3/8" x 3 1/2" Hex Lag Screw-(4)
- (1) A-5- 3/8" x 7" Hex Lag Screw-(4)



Extended Loft Deck Assemblies

PARTS NEEDED

HARDWARE NEEDED


Deck Assembly-CC-101- Universal Filler(3) (4)

A-2- 1/4"x 4 1/2" Hex Lag Screw-

(6) (6)

A-5- 1/4" Uss Flatwasher-

Make 2 of these Assemblies



5' & 5.8 Loft

A-2- 1/4" x 4 1/2" Hex Lag Screw-

Playcenter 6.5 & 7.5 Loft

PARTS NEEDED

CC-101- Universal Filler-

CC-138- Entrapment Board-

CC-141- Entrapment Board-

(1)

(1)


(1)

A-5- 1/4" Uss Flatwasher-

HARDWARE NEEDED (2) (2)

A-3- 3/8" x 3 1/2" Hex Lag Screw-

(8) A-6- 3/8" Uss Flatwasher-(8)




Fort -Loft Assembly

PARTS NEEDED

HARDWARE NEEDED

CC-101- Universal Filler-	(1)	A-2- 1/4" x 4 1/2" Hex Lag Screw-	(2)
CC-138- Entrapment Board-	(1)	A-3- 3/8" x 3 1/2" Hex Lag Screw-	(8)
CC-141- Entrapment Board-	(1)	A-5- 1/4" Uss Flatwasher-	(2)
-		A-6- 3/8" Uss Flatwasher-	(8)




Extended Loft Assembly

PARTS NEEDED

HARDWARE NEEDED

Entrance Assembly-	(1)	W
Bubble Panel Assembly-	(1)	
CC-180- Center Upright-	(4)	
046-16- 8- Hole Facia-	(2)	



Extended Loft Assembly

PARTS NEEDED

HARDWARE NEEDED

046-2- 4- Hole Facia-Rail Assembly(2) (6)


A-3- 3/8" x 3 1/2" Hex Lag Screw-

A-6- 3/8" USS Flatwasher-

(8) (8) (12) A-1- 1/4" x 3" Hex Lag Screw-

(24) A-5- 1/4" USS Flatwasher-

A-2- 1/4" x 4 1/2" Hex Lag Screw-(12)




Extended Loft Tarp Assembly

PARTS NEEDED

HARDWARE NEEDED

CC-181- Tarp Upright- 046-11- Tarp Center- 046-12- Tarp Side Facia-	(2) (1) (2)	A-3- 3/8" x 3 1/2" Hex Lag Screw- A-6- 3/8" USS Flatwasher- A-2- 1/4" x 4 1/2" Hex Lag Screw-	(6) (6) (2)
		A-5- 1/4" USS Flatwasher-	(2)
		B- 2 1/2" Coated Deck Screw-	(8)





Extended Loft Tarp Assembly

PARTS NEEDED

HARDWARE NEEDED

Tarp with Hardware Hardware with Tarp





(Figure A.)- Take one corner of the VINYL TARP and place it flush in the corner. Tap the snap with a blunt object, leaving an indention of the snap in the wood. Repeat this process until all the snaps have been indented in the wood on both sides of the Playcenter.

(Figure B.)- Using the indentions you just made with the snaps, take the 5/8" PHILLIPS SCREW SNAPS and drill one into each indention.

(Figure C.)- Take the corner of the VINYL TARP and start placing the snaps on the PHILLIPS SCREW SNAPS. Fold the VINYL TARP over the top of the UNIVERSAL TARP BOARD. Pull tight and place the snaps on the PHILLIPS SCREW SNAPS.

PARTS NEEDED

CC-110- Wood Roof Support-


CC-055- Peak Support-

(4) (2) WR-2- 3/8" x 3" Carriage Bolt-

HARDWARE NEEDED

(4) WR-15- 1/2" USS Flatwasher-(4) (4) (4) WR-14- 3/8" USS Flatwasher-(4) WR-12- 1/2" Split Lockwasher-WR-7- 3/8" Hex Nut-WR-1- 3/8" Acorn Nut Plated-(4)

WR-4- 1 5/8" Coated Deck Screw-(8)




PARTS NEEDED

HARDWARE NEEDED

047-7- Center Wood Roof Support-	(4)
CC-110- Wood Roof Support- CC-055- Peak Support-	(4) (2)


WR-14- 3/8" USS Flatwasher- (4)
WR-10- 3/8" USS Flatwasher- (4)
WR-4- 1 5/8" Coated Deck Screw- (8)
WR-5- 2 1/2" Coated Deck Screw- (8)



PARTS NEEDED

HARDWARE NEEDED

CC-197- Short Fan Board- (4) CC-006- Center Fan Board- (2) CC-022- Bottom Fan Board- (2) CC-056- Fan Cap- (2) WR-4- 1 5/8" Coated Deck ScrewWR-3- 1 1/2" Coated Deck Screw(24)



PARTS NEEDED

(18)

HARDWARE NEEDED

047-8- Wood Roof Board-

WR-11- 3/8" T-Nut-


WR-14- 3/8" USS Flatwasher-


(6) (6) (6)


WR-8- 3/8" x 1/2" Hex Nut-

WR-4- 1 5/8" Coated Deck Screw-

(144)








Extended Loft

Super 360 Spirell Slidle Unstelleition Incinueil





4465 West Sam Houston Parkway N. Houston, Texas 77041 WWW.TREEFROGSSHOWROOMS.COM

Sections

Page 1: Part List


Page 2: 5.8' Deck Height Assembly

Page 3: 5' & 7' Deck Height Assembly


Page 4: 6.5' Deck Height Assembly

© 2019 KID STRUCTURES INC.

PARTS




Quick Reference Guide #1 For 5.8' Deck Height




NOTE: To spiral in the opposite direction, apply CW turns instead of CCW and vice versa. Turns may need to be adjusted depending on the level of the land.

Quick Reference Guide #2 For 5' & 7' Deck Heights



NOTE: To spiral in the opposite direction, apply CW turns instead of CCW and vice versa. Turns may need to be adjusted depending on the level of the land.


Quick Reference Guide #3 For 6.5' Deck Height




NOTE: To spiral in the opposite direction, apply CW turns instead of CCW and vice versa. Turns may need to be adjusted depending on the level of the land.

Step #1

Assemble the Elbow Section Halves together with the hardware as shown. Note the position of the Overlap Flanges in relation to the direction of the Bolts.






Step #2

Using Nuts, Washers and Bolts, attach the 10 $^{\circ}$ Elbow to Entry Panel in the "Quick Reference" orientation.


<u>Step #3</u>

After properly blocking the slide entrance on the playset, attach the Entry Chute/first Elbow assembly to the playset with the Lag Screws and Washers provided.



Step #4

Using Nuts, Washers and Bolts, attach the 30° Elbow to the previous Elbow in the "Quick Reference" orientation.



<u>Step #8</u>

Place the end of the Exit Chute up against the last Elbow Section and make it level with the ground. If any of the last Elbow bolt holes line up with the Exit Chute attach with Bolts and Washers (possibly 2 Places). For all the holes that don't line up attach with Lag Screws and Washers. (as many as 12 places) Start each Bolt by hand before tightening. Be careful not to overtighten the Lag Screws into the soft plastic.

